

FRONT FORK VULCODER INSTALLATION NOTE:

Installation of Vulcoder using locking fasteners and steel sleeve with rubber washer.

Tighten Vulcoder mounting screws until the rubber washer contacts the Vulcoder case, then tighten screws $\frac{1}{2}$ turn. This should cause slight deformation of the rubber washer.

CAUTION: Over tightening of the mounting fastener will cause damage to the Vulcoder case.

